


The center nozzle (1) is located above the center console in the instrument panel.



P68.10-0514-05