




011	A	163 410 09 01	PROPELLER SHAFT FROM TRANSFER CASE TO FRONT AXLE CODE: -423	001
011	A	163 410 03 01	PROPELLER SHAFT FROM TRANSFER CASE TO FRONT AXLE CODE: 423	001
017	A	163 413 00 84	.SHIM PROPELLER SHAFT TO FRONT AXLE	003
020	A	163 990 03 12	.SCREW PROPELLER SHAFT TO FRONT AXLE	006
023	N	910106 010008	SCREW PROPELLER SHAFT TO TRANSFER CASE	004
032	A	163 410 08 02	PROPELLER SHAFT FROM TRANSFER CASE TO REAR AXLE CODE: -423	001
032	A	163 410 05 02	PROPELLER SHAFT REPLACED BY: A 163 410 12 02 CODE: 423	664 -
032	A	163 410 12 02	PROPELLER SHAFT FROM TRANSFER CASE TO REAR AXLE CODE: 423	001
038	A	163 413 00 84	.SHIM PROPELLER SHAFT TO TRANSFER CASE	003
041	A	163 990 03 12	.SCREW PROPELLER SHAFT TO TRANSFER CASE	006

Part Number	Designation	Footnotes	Ver
910106 010008	SCREW PROPELLER SHAFT TO REAR AXLE		
914130 010205	SCREW REPLACED BY: N 914125 010308		
914125 010308	SCREW REPLACED BY: N 000000 001675		
000000 001675	SCREW INTERMEDIATE BEARING TO FRAME		
163 411 00 25	INTERMEDIATE PLATE		L
163 410 10 01	JOINT PROPELLER SHAFT		
163 410 00 10	INTERMEDIATE BEARING (REPAIR KIT), PROPELLER SHAFT		
163 410 01 10	INTERMEDIATE BEARING (REPAIR KIT), PROPELLER SHAFT		