


MODEL 163 as of 1.9.00 with CODE (245) Trip computer

N41 Trip computer control module



P54.50-0212-06

	Trip computer control module, location	The trip computer control module (TRIP, N41) is located above the inside rearview mirror unit.	
	Trip computer control module, task		GF54.50-P-4100-01GH
	Trip computer control module, design		GF54.50-P-4100-02GH